# 1. How to install driver

## 1.1 Windows 98/98SE Installation

(1) Plug Flash Stick into USB port. System will detect one new hardware and search for proper driver to install.

(2) Choose the first recommend to install.

Downloaded from www.Manualslib.com manuals search engine

(3) Choose setting up from CD ROM.




(4) To execute installation by press “Next”.






Downloaded from www.Manualslib.com manuals search engine

(5) Press “Finish” to complete installation.






Downloaded from www.Manualslib.com manuals search engine